

Bona® Pure Seal

RESILIENT FLOOR SEALER

Specially formulated for the treatment of resilient floors



Bona® Pure Seal is specially formulated to reduce the need for additional coats of color. This formula is designed to lessen the appearance of seams and cracks on resilient surfaces creating a seamless and durable look across the floor.

- Ultra-quick drying for minimal downtime
- Lowers need for multiple coats of color
- Lessens the appearance of seams and cracks
- Durable, two-component technology

Bona® Pure Seal

RESILIENT FLOOR SEALER

Specially formulated for the treatment of resilient floors

TECHNICAL DATA

Ingredients:	Water, polymeric resins, and amorphous silica.
pH-value:	7.9
Solid Content:	0.32
Density:	8.67 lbs./gallon (1.039 g/cm ³)
Viscosity:	(#4 Ford cup @ 25 ° C) approx. 16 seconds
US Regulatory VOC:	<50 g/L
Odor:	Non-offending
Color:	Milky white (wet), Clear and colorless when dry
Pot life:	3 hours
Packaging:	One-gallon jug
Shelf life:	1-year shelf life in unopened container
Storage/Transport:	Nonflammable. Bona® Pure Seal should be stored in a climate-controlled environment. KEEP FROM FREEZING. Do not store above 100° F.
Application Tools:	Bona Microfiber Roller, Cut-in pad
Coverage:	450-550 square feet per gallon (800-1000 SQ.FT. PER GALLON FOR LINOLEUM).
Leveling:	Excellent
Defoaming:	Excellent
Drying time:	2-3 hours
Clean-up:	Application tools should be cleaned with water and stored in an airtight container.
Disposal:	Dispose of any remaining product in accordance with local, state, and federal regulations. Decontaminate empty activator (Part B) bottles prior to disposal by adding 2 oz. of water, recap, shake vigorously and dispose. Recycle container when empty.
Certificates:	Greenguard Gold UL 2818 - 2022 Gold Standard for Chemical Emissions for Building Materials, Finishes and Furnishings

BEFORE USING, READ ALL DIRECTIONS AND SAFETY DATA SHEETS. FOR TECHNICAL ADVICE: Call Bona US at 800-872-5515

RESPONSE

In case of eye contact, flush immediately with water. Get medical attention if irritation occurs. For skin, wash thoroughly with soap and water. If affected by inhalation,

remove to fresh air. If swallowed, drink 1 or 2 glasses of water to dilute. Do not induce vomiting. Get medical attention if symptoms occur.

Bona® Pure Seal

RESILIENT FLOOR SEALER

Specially formulated for the treatment of resilient floors

RECOMMENDED USE

VCT, VAT, LVT, PVC, LINOLEUM, RUBBER

COMPATIBILITY

Bona® Pure Seal will adhere to resilient floor systems - VCT, VAT, linoleum, PVC, LVT, and rubber after proper preparation and dry times. ALWAYS PREPARE A SAMPLE

OR TEST AREA TO DETERMINE COMPATIBILITY, APPEARANCE AND DESIRED RESULTS.

BONA PRODUCT SYSTEM

Apply Bona Pure Seal prior to Bona Pure Color (optional) followed by 2 coats of Bona Pure HD. Follow label

directions. NOTE: Bona Pure Seal is required for linoleum floors at a rate of 800-1000 square feet per gallon.

PREPARATION

1. Evaluate the Floor - Inspect the entire floor for scuff marks, current finish condition/peeling, cupping and other damage, and overall floor appearance. For cracks and small voids in the tile, use Bona® Resilient Floor Repair (following label instructions). 2. Prepare the Floor - Gather all recommended tools and materials for the job. Secure the work area and post signs on entrance doors with "Do Not Enter." Use the Bona® Pro Series Microfiber Dry Dusting Pad to dust the floor.

Complete removal of existing acrylic or wax coatings is required. to ensure proper adhesion. 1. Strip and rinse floor using a floor finish stripper designed to remove commercial acrylic floor finish, polish or wax (mix per label directions). 2.

Auto scrub or wet vacuum the entire floor to remove all residue from stripping. 3. Next, use the Bona FlexiSand DCS Buffer and 80 or 120-grit Bona Diamond abrasives on a Bona MultiDisc and clean water to wet abrade the entire work area. Work in sections, making sure to overlap each section. 4. Post-Abrasion Cleaning - Auto scrub or wet vac the entire floor to clean the floor and remove any remaining residue. 5. Wet mop or wet tack using a Bona Pro Series Microfiber Wet Cleaning Pad to neutralize the surface. 6. Allow floor to dry completely before coating. IF FLOOR IS LINOLEUM, MUST DRY FOR A MINIMUM OF 24 HOURS TO AVOID ADHESION ISSUES FROM EXCESS MOISTURE.

MIXING INSTRUCTIONS

SHAKE WELL BEFORE USING. DO NOT THIN. 1. Shake Bona Pure Seal (Part A) well for 45 seconds. 2. Add Bona® HD Hardener (Part B) to Bona® Pure Seal (Part A). One 10.38 oz. bottle of hardener will activate one gallon of Bona® Pure Seal. To mix finish amounts of less than one

gallon, use a 1:11.33 ratio. 3. Immediately shake mixture vigorously for 45-60 seconds. 4. Insert supplied filter into bottle. 5. Let sit for 5-10 minutes before applying. Bona® Pure Seal CANNOT BE REHARDENED

Bona® Pure Seal

RESILIENT FLOOR SEALER

Specially formulated for the treatment of resilient floors

APPLICATION

APPLICATION

1. Pour a 4"-6" wide line of Bona Pure Seal along the starting wall. 2. Using a clean, pre-dampened applicator, roll the sealer uniformly, being careful not to leave excess puddles or heavy spots as you work your way across the room. **BE SURE YOU ARE USING THE RECOMMENDED COVERAGE OF 450-550 SQ. FT. PER GALLON (800-1000 SQ.FT. PER GALLON FOR LINOLEUM). DO NOT SPREAD TOO THIN.** 3. At the end of each run, pour a new 4-6" line on your wet edge and repeat the rolling process. Do not push too hard or too fast to avoid dripping or splattering. 4. Allow the first coat to dry 2-3 hours. Mechanical ventilation can be used. High humidity and/or low temperature conditions will extend the dry time (recommended conditions of 65-80°F/40-60% relative humidity). Once dry, apply the Bona® Pure Color or Bona® Pure HD depending on the desired look, as directed. For added protection, protective shoe coverings should be worn when coating over newly applied coats.

CLEARCOATING:

LVT / LVP floors in need of a maintenance coat can be periodically recoated to ensure a lasting, attractive surface.

CAUTION! To avoid adhesion failures if waxes, acrylics or polish have been used on top of the Bona Pure HD, you must use a floor finish stripper designed to remove commercial acrylic floor finish, polish or wax (mix per label directions) prior to step 3 of this recoating procedure. 1. Vacuum, strip floor if applicable, and clean using Bona Prep Recoat Adhesion Conditioner in a Bona PowerScrubber or an autoscrubber with 320-grit or equivalent conditioning pads. If you use a Bona PowerScrubber, fit the machine with the red bristle brushes. For highly textured flooring, follow up using the Bona Recoat System Abrasive Brush on a Bona FlexiSand DCS® Buffer, and remove any wet residue and allow the floor to dry. 2. Use Bona PowerScrubber or an autoscrubber to remove any wet residue and allow the floor to dry. 3. To ensure successful adhesion of the new topcoat, abrade floor using 120-grit Bona Diamond Abrasives mounted on a Bona MultiDisc and Bona FlexiSand DCS Buffer. 4. Thoroughly vacuum the entire surface to be coated, followed by a wet tack to remove any dust from the abrasion process. 5. Follow mixing and finishing instructions of Bona Pure HD.

Bona US

24 Inverness Place East Suite 100
Englewood, CO 80112