


Bona Belt Previous Models AMO110018.3 Belt wheel subframe



Bona Belt Previous Models AMO110018.3 Belt wheel subframe

.	ASO118500.3	Working pressure bracket grey
001a .	ASO118002	Wheel bolt 100 mm L=85 Left
001b .	ASO118003	Wheel bolt 100 mm L=75 right
005 .	ASO965600	Washer BRB 10,5X22X2 FZB
006 .	ASO961600	Nut Lock-King M10 fzb
007 .	ASO117007	Wheel complete
008 .	ASO961500	Nut Lock-King M8 fzb
009 .	ASO930012	Circlip ring SGA12
010 .	ASO968203	Spacer 12x18x0,3
011 .	ASO934026	Spacer 20x12,2x11
012 .	ASO918012	Ball bearing GE12E
013a .	ASO934037	Spacer 18x12,5x25 Left side
013b .	ASO934013	Spacer 18X12,2X15 Right side
017 .	ASO118017	Lower connection rod
018 .	ASO953518	Screw MF6S M8X20
027 .	ASO118027	Wheel sub-frame
031 .	ASO118031	Control bracket
032 .	ASO931022	Circlip ring SGH22
033 .	ASO945722	Plastic cover wheel sub-frame
037 .	ASO118155	Spacer sleeve short
039 .	ASO118039.3	Working pressure bracket
040 .	ASO118040	Working pressure axle
055 .	ASO118155	Spacer sleeve short
069 .	ASO945144	Locking knob WN730 T40-M8x20

070 .	ASO940070	Spring SS1774 2x18x70
084 .	ASO945035	Spring bracket M8x35
086 .	ASO118600	Threaded rod complete
087 .	ASO118700.3	Arm complete for wheel 100 mm
104 .	ASO951418	Screw M6S M6x20 fzb
105 .	ASO968002	Spacer DB 6x12,5x0,2
121 .	ASO952413	Screw MC6S M6x10 fzb
131 .	ASO118131	Spacer sleeve
141 .	ASO930020	Circlip ring SGA20