


Bona Midi AMO150003.0 Midi housing



Bona Midi AMO150003.0 Midi housing

.	ASO111020	Tube holder
.	ASO111040	Belt cover
.	ASO116600	Dust tube
.	ASO151500	Front and side cover compl.
.	ASO152522	Side roller complete
001 .	ASO151001	Chassis
003 .	ASO121003	Front cover GM
004 .	ASO121004	Axle
005 .	ASO151004	Side cover Midi
018 .	ASO111018	Tube holder
020 .	ASO116600	Dust tube
021 .	ASO111021	Handle bracket
022 .	ASO152522	Side roller complete
023 .	ASO910626	Ball bearing 626-2RSH
024 .	ASO968002	Spacer DB 6x12,5x0,2
025 .	ASO958412	Screw MELC6S M6X10
031 .	ASO958620	Wingheaded screw M10x30
035 .	ASO951519	Screw M6S M8x25 fzb
036 .	ASO965500	Washer
037 .	ASO950519	Screw MCS M8x25 fzb
038 .	ASO111038	Locking plate for tilt support
039 .	ASO965500	Washer
040 .	ASO927057	O-ring 57,15x3,5
041 .	ASO111041	Motor bracket, rear
042 .	ASO111042	Belt cover

043 .	ASO111043	Bracket
053 .	ASO928061	Rubber string 6x200 (cut)
058 .	ASO951518	Screw M6S M8x20 fzb
059 .	ASO965050	Washer 8X22X1,5
061 .	ASO929006	Dust brush front cover L=280
062 .	ASO929023	Profile front cover L=280
063 .	ASO929041	Sealing strip
064 .	ASO953313	Screw MF6S M5X10
066 .	ASO111066	Spring
067 .	ASO955412	Screw MSK6SS M6x8
068 .	ASO945128	Lifting handle GM-GMU
069 .	ASO951528	Screw threaded up M6S M8x70fzb
075 .	ASO929032	Sealing strip belt cover, rear
077 .	ASO950416	Screw MCS M6x16 fzb
078 .	ASO960400	Nut M6M M6 fzb
099 .	ASO935550	Cylinder pin 8x50
100 .	ASO955412	Screw MSK6SS M6x8
102 .	ASO953419	Screw MF6S M6X25
140 .	ASO937217	Pop rivet 4,8 x 16,7
141 .	ASO991001	Dust bag with zipper
158 .	ASO929031	Sealing strip belt cover front